



Water Testing

Photometer MD50

New!

smart
NFC)))
connection

The new MD50 Single Parameter-Photometer

– Your Ultimate Solution for Precision Testing
and Unmatched Ease!

The MD50 series offers a comprehensive range of single parameter photometers that meet the most diverse needs of water treatment.

Whether you're monitoring chlorine, chlorine high range, chlorine dioxide, ozone, monochloramine, urea, suspended solids, hazen, molybdenum, copper, or phosphate levels, there's an MD50 variant tailored to your requirements.



Single parameter

Simplified Operation

Discover unparalleled ease with the MD50's single parameter design and language-free user interface. Icons and animations guide you effortlessly through the testing, while green and red backlighting instantly communicate results status and errors. Programming options for one user-defined method and easy instrument updateability empower you to customize your testing protocols effortlessly.

Enhanced Efficiency

Experience unmatched accuracy and speed of measurement with our innovative new optics, ensuring precise readings in record time. The one-time zero feature guarantees rapid sampling saving precious time in your daily operation. Plus, the ability to select your favorite reagent type – be it tablet, powder, or liquid – adds to the flexibility and convenience of the MD50 series.

Built to Last

Rugged industrial design, complete with rubber-protected sides, ensures the MD50 stands up to the toughest conditions. Experience unmatched durability and reliability, even in demanding environments with a waterproof IP67 rating. Powered by 2 AA batteries, the MD50 delivers exceptional battery life, enabling up to 5000 measurements per battery usage for an uninterrupted testing session.

Water testing Applications for the MD50 series span a wide range, including Boiler Water, Cooling Water, Disinfection Control, Drinking Water Treatment, Pool Water Control, Pool Water Treatment, Raw Water Treatment, and Wastewater Treatment. No matter the application, Lovibond® provides versatile reagents in tablet, powder, or liquid form, ensuring you have the best solution from a single source.

Elevate your testing experience with the MD50 Single Parameter Photometer – where simplicity meets precision, and durability reigns supreme.



smart
NFC
connection



AquaLX® App



Download on the
App Store



GET IT ON
Google Play

Standards for photometry

Accurate analysis results are essential not only at the point where water enters the public supply but also throughout various stages in industrial processes and laboratory settings. Adhering to standards, norms, and quality assurance specifications is crucial for achieving precise water analysis. This level of accuracy is attainable only with the right equipment and optimal technical quality. Regular checks using reference, verification, and validation standards are necessary to ensure that both the chosen methods and the measuring devices consistently produce reliable results.



Reference Standard Kit Chlorine
0.2 and 1.0 mg/L Code: 275620
0.5 and 2.0 mg/L Code: 275621
1.0 and 4.0 mg/L Code: 275622

Verification Standard Kit
Code: 215700

AquaLX® App

Improved data transfer & storage

Enjoy smooth, effortless data management like never before. With NFC technology and the AquaLX® app from Lovibond®, data can be transferred effortlessly.

With the ability to store up to 100 data sets, the MD50 ensures you don't have to compromise on data storage. GLP-compliant data storage creates confidence. The MD50 guarantees data integrity at every step, giving you peace of mind that your results are accurate.



Waterproof USB-C connection
for data export and updates



Delivery content

- MD50
- 2 x AA Batteries
- Screwdriver
- 3 x Stirring rods
- 3 x 24 mm Vials with lid
- Syringe
- Cleaning brush
- USB-C to USB-A Cable
- Instruction manual
- Reagents (depends on variant)

Versions

MD50 Variants	Method No.	Method	Measuring range	Type of reagents	Code
MD50 Chlorine	M100	Cl (free, total, comb.)	0,02–6 mg/L Cl ₂	Tablets	280100
	M101	Cl (free, total, comb.)	0,02–4 mg/L Cl ₂	Liquid	280102
	M103	Cl HR (free, total, comb.)	0,1–10 mg/L Cl ₂	Tablets	
	M110	Cl (free, total, comb.)	0,02–2 mg/L Cl ₂	Powder	280105
	M112	Cl (free, total, comb.)	0,1–10 mg/L Cl ₂	Powder	
MD50 Chlorine Dioxide	M120	ClO ₂	0,02–11 mg/L ClO ₂	Tablets	280120
	M122	ClO ₂	0,04–3,8 mg/L ClO ₂	Powder	280125
MD50 Ozone	M300	Ozone	0,02–2 mg/L O ₃	Tablets	280130
	M301	Ozone	0,015–1,2 mg/L O ₃	Powder	280135
MD50 Chlorine HR (KI)	M105	Cl HR (KI)	5–200 mg/L Cl ₂	Tablets	280140
	M212	NaOCl	0,2–16 % NaOCl	Tablets	
MD50 Monochloramine	M63	MCA, NH ₃	0,02–4,5 mg/L Cl ₂	Powder + Liquid	280150
	M64	MCA, Cl ₂	0,02–4,5 mg/L Cl ₂	Powder + Liquid	
MD50 Urea	M390	UREA	0,1–2,5 mg/L CH ₄ N ₂ O	Liquid	280160
	M391	UREA	0,2–5 mg/L CH ₄ N ₂ O	Liquid	
MD50 Suspended Solids	M384	SuS	10–750 mg/L TSS	<i>No reagents required</i>	280170
MD50 Hazen	M204	Hazen	10–500 Pt-Co Units	<i>No reagents required</i>	280180
MD50 Molybdenum	M251	Mo LR	0,03–3 mg/L Mo	Powder + Liquid	280190
	M250	Mo	0,6–30 mg/L Mo	Tablets	280191
	M252	Mo HR	0,3–40 mg/L Mo	Powder	280195
MD50 Copper	M150	Cu (free, total, diff.)	0,05–5 mg/L Cu	Tablets	280200
	M153	Cu	0,05–5 mg/L Cu	Powder	
MD50 Phosphate	M320	PO ₄	0,05–4 mg/L PO ₄	Tablets	280210
	M323	PO ₄	0,06–2,5mg/L PO ₄	Powder	280215

Accessories

- 24 mm Round cuvette
Set with 5 Pc. (197629) or 12 Pc. (197620)
- Stirring rod Set 10 Pc. (364130)
- Measuring beaker (384801)
- Plastic funnel with handle, white (471007)
- Cuvette stand (418951)
- USB Cable (19820-081)
- Cleaning cloth (197635)
- Cleaning brush (380230)

Lovibond® Website



A landing page created especially for you, where you get the most important information with one click.

Tintometer GmbH

Tel: +49 (0) 231/94510-0
sales@lovibond.com
Germany

Tintometer China

Tel: +86 10 85251111 ext. 330
Customer Care China: 4009021628
Fax: +86 10 85251001
chinaoffice@tintometer.com
China

The Tintometer Limited

Tel: +44 1980 664800
support@lovibond.uk
UK

Tintometer South East Asia

Tel: +60 (0)3 3325 2285/6
lovibond.asia@tintometer.com
Malaysia

Tintometer Inc.

Tel: +1 941 756 6410
sales@lovibond.us
U.S.A.

Tintometer India Pvt. Ltd.

Tel: 1800 102 3891
indiaoffice@lovibond.in
India

Tintometer Spain

Tel: +34 661 606 770
sales@tintometer.es
Spain

Tintometer Brazil

Tel: +55 11 3230 6410
sales@tintometer.com.br
Brazil