



# MD150

## Multiparameter Photometer

new

smart  
**NFC** connection

Your daily companion  
for water analysis.

IP67

### Next generation in water testing:

- Wireless (NFC) and wired (USB-C) data transfer options
- Free Software and App for easy data management
- Enhanced optics for faster operation
- One Time Zero (OTZ) for more convenience and time efficiency
- Intuitive user interface with easy-use icons and animations
- Exceptional durability to withstand demanding conditions

# FEATURES AT A GLANCE



Multi-Parameter Instrument  
for fast measurements

Intuitive operation

IP67

GLP compliant  
data backup


Data transfer via  
NFC (AquaLX®)



Waterproof USB-C connection  
for data export & updates



Display with icons  
& animations



Coloured backlight:  
Green: in measuring range  
Red: outside measuring range or error



## Perfect for a wide range of applications

- **Multiparameter combinations**

The MD150 provides essential parameters for pool water monitoring and disinfection control, including Chlorine, Bromine, Ozone, Chlorine Dioxide, pH, Cyanuric Acid, Alkalinity, and Calcium Hardness.

- **Factory programmed methods**

The MD150 comes with pre-programmed methods for pool and various other applications, ready to use out of the box.

- **Flexible reagent options: compatible with tablets, powder or liquid**

Compatible with various reagent types, simply select your preferred reagent in the settings, and the method list will display only the relevant options.

## Robust design for reliable performance

- **Built for durability**

The MD150 features a durable design with rubber-protected sides ensuring reliability even in demanding environments. With its IP67 rating, the instrument offers full protection against dust and water immersion.

- **Ergonomic design**

The MD150 is a compact, handheld instrument ideal for the use of the poolside, in the field, or in the lab. Its compact size and side protections ensure a firm grip, while rubber feet prevent slipping, enabling for single-handed operation.

## Effortless operation and precision

- **Quick and accurate results**

The innovative optical system of the MD150 provides exceptional accuracy and fast results, delivering precise measurements in record time.

- **One-Time-Zero function**

Save operation time with the One-Time-Zero function, which remains valid for 8 hours unless the instrument is turned off.



smart  
**NFC**  
connection



## AquaLX® App



## Instant Data Management

### • Data transfer – NFC / USB-C

Easily transfer data wirelessly via NFC to the AquaLX® app or via USB-C cable to Lovibond® Data Expert. Data can be exported in CSV format for use in programs like Excel.

### • GLP (Good Laboratory Practice) compliance

The MD150 automatically records and saves a protocol for every change, ensuring data quality and integrity by tracking any adjustments that could impact measurement results.

### • Automatic data storage

The MD150 automatically stores the last 100 readings and protocols with a time/date stamp and retains the data even during battery changes.

### • Keep your instrument up to date

Easily update the firmware and methods in seconds using Lovibond® Data Expert. Updates are available on the instrument's webpage.

### • User defined method

With the free of charge Lovibond® Data Expert, you can create custom methods.

## NFC: Wireless data transfer

NFC (Near Field Communication) is a short-range wireless technology for secure data transfer between devices in close proximity. The NFC chip in the MD50/MD150 enables seamless data transfer to Android and iOS devices. Simply activate NFC on the instrument, open the AquaLX App, and place your smartphone over the device to transfer selected data for instant evaluation.



### Delivery content

The MD150 comes ready to use, including everything you need for daily water analysis.

- MD150
- 2 x AA Batteries
- Screwdriver
- 3 x Stirring rods
- 3 x 24 mm Vials with lid
- Syringe
- Cleaning brush
- USB-C to USB-A Cable
- Instruction manual
- Reagents (depends on variant) liquid, powder or tablets

MD150 Cl-pH Set -2  
Part No. 282102

## Photometry Standards

Ensuring accurate water analysis requires proper equipment and regular checks using reference, verification, and validation standards.

Lovibond® offers the following verification and reference kits, compatible with all MD150 variants to help maintain reliable measurement.



Reference Standard Kit Chlorine\*  
0.2 and 1.0 mg/L Code: 275630  
0.5 and 2.0 mg/L Code: 275631  
1.0 and 4.0 mg/L Code: 275632

Reference Kit pH\*  
Code: 275635

Verification Standard Kit  
Code: 215700

\* for tablet method only

# AVAILABLE VARIANTS

## Lovibond® – Setting Standards in Flexibility

Lovibond® is the only brand on the market to offer reagents for chlorine determination in all three forms – liquid, tablet, and powder.

This unmatched variety allows us to meet the diverse needs of industries and applications worldwide. Our mission is not only to provide you with premium quality but also to deliver tailored solutions for your specific challenges.

The MD150 multiparameter photometer offers you the flexibility to select your preferred reagent type while still enabling the use of established methods across different reagent forms when needed. The table showcasing the various MD150 options is based on years of user feedback and satisfaction.

MD150 Variant Order Code Kit	Description	Parameter	Measuring Range	Reagent form included
282100	<b>MD150 Cl-pH Set-1</b>	Chlorine (free, total, comb.) pH	0,01 - 6 mg/L Cl <sub>2</sub> 6,5 - 8,4	Tablet Tablet
282102	<b>MD150 Cl-pH Set-2</b>	Chlorine (free, total, comb.) pH	0,02 - 4 mg/L Cl <sub>2</sub> 6,5 - 8,4	Liquid Liquid
282105	<b>MD150 Cl-pH Set-3</b>	Chlorine (free, total, comb.) pH	0,02 - 2 mg/L Cl <sub>2</sub> 6,5 - 8,4	Powder Tablet
282110	<b>MD150 Cl-pH-CyA Set-1</b>	Chlorine (free, total, comb.) pH Cyanuric acid HR	0,01 - 6 mg/L Cl <sub>2</sub> 6,5 - 8,4 10 - 200 mg/L CyA	Tablet Tablet Tablet
282112	<b>MD150 Cl-pH-CyA Set-2</b>	Chlorine (free, total, comb.) pH Cyanuric acid HR	0,01 - 6 mg/L Cl <sub>2</sub> 6,5 - 8,4 10 - 200 mg/L CyA	Liquid Liquid Tablet
282120	<b>MD150 Cl LR/HR-ClO<sub>2</sub></b>	Chlorine (free, total, comb.) Chlorine HR(KI) Chlorine dioxide	0,01 - 6 mg/L Cl <sub>2</sub> 5 - 200 mg/L Cl <sub>2</sub> 0,02 - 11 mg/L ClO <sub>2</sub>	Tablet Tablet Tablet
282130	<b>MD150 Cl-ClO<sub>2</sub>-pH-K<sub>S4,3</sub></b>	Chlorine (free, total, comb.) Chlorine dioxide pH Acid capacity (K <sub>S4,3</sub> ) Total alkalinity	0,01 - 6 mg/L Cl <sub>2</sub> 0,02 - 11 mg/L ClO <sub>2</sub> 6,5 - 8,4 0,1 - 4,0 mmol/L K <sub>S4,3</sub> 5 - 300 mg/L CaCO <sub>3</sub>	Tablet Tablet Tablet Tablet Tablet
282140	<b>MD150 Cl-Br-ClO<sub>2</sub>-O<sub>3</sub>-pH</b>	Chlorine (free, total, comb.) Bromine Chlorine dioxide Ozone pH	0,01 - 6 mg/L Cl <sub>2</sub> 0,05 - 13,5 mg/L Br <sub>2</sub> 0,02 - 11 mg/L ClO <sub>2</sub> 0,02 - 2 mg/L O <sub>3</sub> 6,5 - 8,4	Tablet Tablet Tablet Tablet Tablet
282150	<b>MD150 Cl-Br-pH-CyA-TA-CaH</b>	Chlorine (free, total, comb.) Bromine pH Cyanuric acid HR Total alkalinity Acid capacity (K <sub>S4,3</sub> ) Calcium hardness	0,01 - 6 mg/L Cl <sub>2</sub> 0,05 - 13,5 mg/L Br <sub>2</sub> 6,5 - 8,4 10 - 200 mg/L CyA 5 - 300 mg/L CaCO <sub>3</sub> 0,1 - 4,0 mmol/L K <sub>S4,3</sub> 5 - 500 mg/L CaCO <sub>3</sub>	Tablet Tablet Tablet Tablet Tablet Tablet Tablet

Handbook of Methods –  
Available in 10 languages



Further information about our  
photometers can be found here

**Tintometer GmbH**  
Tel: +49 (0) 231/94510-0  
sales@lovibond.com  
Germany

**Tintometer China**  
Tel: +86 (0) 85251111 ext. 330  
Customer Care China: 4009021628  
Fax: +86 10 85251001  
chinaoffice@tintometer.com  
China

**The Tintometer Limited**  
Tel: +44 1980 664800  
support@lovibond.uk  
UK

**Tintometer South East Asia**  
Tel: +60 (0)3 3325 2285/6  
lovibond.asia@tintometer.com  
Malaysia

**Tintometer Inc.**  
Tel: +1 941 756 6410  
sales@lovibond.us  
U.S.A.

**Tintometer India Pvt. Ltd.**  
Tel: 1800 102 3891  
indiaoffice@lovibond.in  
India

**Tintometer Spain**  
Tel: +34 661 606 770  
sales@lovibond.com  
Spain

**Tintometer Brazil**  
Tel: +55 11 3230 6410  
sales@lovibond.us  
Brazil

